

All of the follow exit device trims can be used on common rim exit devices.

NO TRIM (EXIT ONLY)	No exterior trim. No pull handle, no cylinder, no entering from the out- side unless someone on the inside hits the panic bar to open the door.
ENTRY LEVER	Entry function keyed lever trim outside. Key locks and unlocks the lever. With a key you can enter from the outside when the lever is locked. With the key you can unlock the lever to allow anyone to enter. Supplied with two keys x C-keyway.
STOREROOM LEVER	Storeroom function keyed lever trim outside. Key unlocks lever and once the door closes/latches it remains locked (positive locking) until someone with a key opens the door or someone inside hits the panic bar to open the door. With a key you can enter form the outside when the lever is locked. Storeroom function will always lock when the door closes or is latched. Supplied with two keys x C-keyway.
ENTRY LEVER X SFIC	Entry function keyed lever trim outside. Key locks and unlocks the lever. With a key you can enter from the outside when the lever is locked. With the key you can unlock the lever to allow anyone to enter. The IC lever is provisioned to receive an SFIC (Small Format Interchangeable Core) which is supplied by others.
STOREROOM LEVER X SFIC	Storeroom function keyed lever trim outside. Key unlocks lever and once the door closes/latches it remains locked (positive locking) until someone with a key opens the door or someone inside hits the panic bar to open the door. With a key you can enter form the outside when the lever is locked. Storeroom function will always lock when the door closes or is latched. The IC lever is provisioned to receive an SFIC (Small Format Inter- changeable Core) which is supplied by others.
PASSAGE LEVER	Passage function lever trim outside. Lever always unlocks for anyone to enter from outside.
CYLINDER & PULL HANDLE	Double finger pull handle supplied with rim cylinder in center of pull han- dle. Rim cylinder is included with two keys x C-keyway.